

# INDULINE WOODCOATING SYSTEMS

## Induline Mix & Go



**Image 1**  
Carefully open a 0.75 l can.  
(Using a metal spatula)

**Image 2**  
Remove both plastic bottles from the can.

**Image 3**  
Pour the contents of the Induline Mix & Go Brushing Additive into the empty tin. (This is a pre-measured ratio of 1 part retarder to 10 part paint).

**Image 4**  
Add the appropriate topcoat type i.e Induline DW-6XX or LW-7XX to the tin, leaving a gap of approximately 1cm (no less), below the underside of the tin rim. A 2K mixing cup can be used for de-canting.

**Image 5**  
Stir well with a good stick or spatula for approximately one minute, to achieve a fully blended liquid. Close the tin.

**Image 6**  
Label the tin with a fine permanent marker stating the product used - (e.g LW-700/20 – Afrosia)

**Image 7**  
Using the remaining empty plastic bottle; fill with the appropriate primer / base stain.

**Image 8**  
Label the bottle with a fine permanent marker stating the product used - (e.g GW-360 – Afzelia)